



Maintenance Tips

Proper care of your Thermoproof Products is important. Clear weep holes of construction debris upon installation and periodically thereafter to allow drainage. An old toothbrush may help to clear the openings. Please ensure that the track area is kept clean. Vacuum frequently to remove any debris.

When cleaning your Thermoproof Products, use only warm water and mild detergent and a clean cloth to clean glass and vinyl. Do not use a high power spray to clean your windows or glass. Avoid the use of razor blades, sharp tools, or a dirty cloth, which may cause scratching. Avoid cleaning your glass in direct sunlight. Screens can be cleaned using a mild soap and water solution and a soft brush. Always remove your screens before cleaning. It is recommended to remove interior screens during winter months to reduce potential condensation problems.

All hardware must be lubricated regularly and cleaned of debris. Use a spray silicone product to lubricate moving parts. Be careful not to over lubricate. Clean any drips or spills. In salt-air environments, it may be necessary to clean and lubricate twice per year.

Care should be taken to ensure weather stripping and hardware is not painted over which will result in them not performing as intended. This can void your warranty.

Inspect the caulking sealing the window or door against the building annually and replace or repair any area that is cracked to prevent leaking.

Adjust patio doors and screens rollers for proper operation.